

Instructions for enabling PARENTAL CONTROLS with ElbertonNET's on-screen guide

*TURNING OFF ADULT AND MATURE TITLES IN THE ON-SCREEN GUIDE*

1. Press "MENU" twice to bring up the full menu
2. Arrow down and to the right to "Parental Control." Select with "OK/SEL."
3. Enter your 4 digit PIN number, or if you have never accessed Parental Control before, enter a new PIN number. Confirm the PIN if needed.
4. Arrow right and down to "Hide Titles." Select with "OK/SEL."
5. Select the option you want—to hide both Adult and TV-MA titles, or just Adult titles. Select with "OK/SEL."
6. Then "EXIT." Check the on-screen program guide, and your selection should be reflected in the guide now.